

# E300

(Ram Plus)

User Manual

# Contents

|                                              |           |
|----------------------------------------------|-----------|
| <b>1. Safety and Performance .....</b>       | <b>3</b>  |
| <b>3. Preparing for use .....</b>            | <b>12</b> |
| 3.1 Install SIM Card .....                   | 12        |
| 3.2 Install Memory Card (T-FLASH Card) ..... | 12        |
| 3.3 Charge the battery .....                 | 12        |
| <b>4. Basic Functions .....</b>              | <b>13</b> |
| 4.1 Dial Call .....                          | 13        |
| 4.2 Adjust Volume .....                      | 13        |
| 4.3 Answer the incoming call .....           | 13        |
| 4.4 Call Process .....                       | 14        |
| <b>5. Main Menu .....</b>                    | <b>14</b> |
| 5.1 Call Center .....                        | 14        |
| 5.1.1 Call history .....                     | 14        |
| 5.1.2 Call Settings .....                    | 15        |
| 5.2 Phonebook .....                          | 17        |
| 5.3 File Manager .....                       | 18        |
| 5.4 Organizer .....                          | 18        |
| 5.5 Message .....                            | 18        |
| 5.6 Multimedia .....                         | 20        |
| 5.6.1 Camera .....                           | 20        |
| 5.7 Network Service .....                    | 23        |
| 5.9 Settings .....                           | 23        |

|                                     |    |
|-------------------------------------|----|
| 6. Appendix .....                   | 26 |
| Common problems and solutions ..... | 27 |

## 1. Safety and Performance

### ◆ Personal

- ◆ Interference might cause by poor shielding performance of medical devices such as hearing aids and heart pacemakers. Consult to medical device manufacturer or your doctor before using mobile phone.
- ◆ Please turn off the phone in medical facilities. These places include hospitals and rest homes and other medical establishments because these facilities may be using equipments sensitive to external RF signal.
- ◆ If you are using personal medical devices, please consult to these manufacturers to confirm that they are adequately shielded from around the RF signal. You can also ask your doctor for the relevant information.
- ◆ Users suffering from heart disease should pay special attention to the setting of ring tone volume and vibration prompts.
- ◆ In oil storages, chemical factories or any place which have explosive gases or the location of explosive production process, we should pay special attention to the RP devices using restrictions. In standby state, your mobile phone sill launches the electromagnetic signal. You shall turn off the phone if being requested.
- ◆ To pay attention to traffic safety. Please do not use mobile phones while driving. Please park your car before you use the phone.
- ◆ If your phone is lost or stolen, please immediately notify the telecommunications sector, in order to disable the SIM card. It will protect you from the economic losses caused others to take the call.
- ◆ When you contact the telecommunications department or distributor, they may need to know your phone's IMEI number. It's printed on the label on the back of the phone (or input "\*\* # 06 #" to check the IMEI number). Please put the number down and keep for the future needs.

- ◆ To avoid the misused of the phone, please take preventive measures such as: set up mobile phone SIM card PIN code or personal security code and modify in a timely manner when others know.
  - ◆ Do not remove the battery in standby state mode, it will result in the loss of user data.
- When you leave your car, please do not put the mobile phone in a place easy to be seen. You shall take it with you or put it in the trunk.
- ◆ Do not let the children touch the mobile phone, charger or battery.

### ◆ **Mobile Phone**

Mobile phone contains sophisticated electronic circuitry, magnets and battery systems, it should be handle with care. In particular, you should pay attention to the following points:

- ◆ Your mobile phone will generate electromagnetic fields, please do not place it with magnetic storage media, such as computer disk.
- ◆ Using mobile phone near the TV, radio, personal computers and other electrical equipments may cause interference, thus affecting the performance of the phone.
- ◆ Whenever, do not keep the mobile phone and its accessories come into contact with the liquid or in a damp environment.
- ◆ Please do not put the mobile phone in the place that the temperature is too high or too low.
- ◆ Please do not place the mobile phone on fire or near the lit cigarette.
- ◆ Please do not scribble on the mobile phone.
- ◆ Please do not have any rough throw behavior on your mobile phone.
- ◆ Please do not put the mobile phone and computer disks, credit cards, travel cards or other magnetic objects together. Otherwise, the information stored in the disk or credit card may be affected by the mobile phone.
- ◆ Please do not place the mobile phone or battery under sunlight. Do not attempt to disassemble the mobile phone or any other attachment.
- ◆ Can only use a damp or anti-static cloth to wipe the mobile phone. Do not use dry cloth with static electricity to wipe the phone. Do not use chemical reagents or abrasive cleanser otherwise it may damage the cabinet.

- ◆ The headset may be hot during normal using and the mobile phone may be hot when charging.
- ◆ Do not leave the mobile phone without battery or with empty battery for a long time otherwise the data may be lost.
- ◆ Mobile phone contains some metallic substances which may cause allergies.
- ◆ If you turn on the vibration function, please keep the mobile phone away from the heat source (such as radiator) and to avoid the phone slipped from the desktop due to vibration.
- ◆ Please try to avoid scratching the touch screen. Do not use common pen or other sharp objects to write on the touch screen.

### ◆ **Battery**

- ◆ Please do not short circuit battery equipment, it will damage the battery and may cause fire or explosion.
- ◆ You must not put the battery into the fire lest it will cause an explosion. Used batteries should be returned to the supplier or put in the designated collection points. Do not put them in the household waste.
- ◆ Please do not use metal objects (such as coins or key ring) to contact the battery endpoint because it may cause short circuit.
- ◆ Please do not remove the phone battery in the boot state.
- ◆ The internal components of the mobile phone battery can only be replaced by professional maintenance engineer. If you use wrong type of battery, it may cause explosion. Be sure to deal with the used batteries according to the manufacturer's instructions.
- ◆ Use any non-phone manufacturer specified battery or charger, there will be potential danger resulting in damaging the mobile phone which is out of warranty.

 Note: If the battery is damaged, you should avoid touching the things inside. If it contacts the skin, please wash your hands with lots of water. In the necessary circumstances, you should seek medical help.

### ◆ **On the road**

- ◆ You must focus on road for safety driving.
- ◆ Please comply with all the requirements of the local traffic safety regulations.
- ◆ Before dialing or receiving calls, you should pay close attention to local legal system for mobile

wireless phone using, and pay attention in using.

- ◆ Please turn off your mobile phone when refueling, the same situation applies to ban the use of a two-way radio equipment. Please do not take any hazardous material which is inflammable, explosive with mobile phone together otherwise the internal spark may cause burns.

#### ◆ On the plane

- ◆ Please turn off the phone while you are in the plane or near the plane. It is illegal to use mobile phone in the plane. It could be dangerous for aircraft operation and it may also disrupt mobile phone networks.
- ◆ In an emergency situation, you can use the phone according the safety regulations and under the consent of the crew's permission.

#### ◆ Other manufacturers' equipments

- ◆ Use unauthorized equipments, cables or accessories of other manufacturers may lead to the phone's warranty failure. It may also affect the normal use of the mobile phone. Please be sure to use the cable as included in the package.

#### ◆ Maintenance Service

- ◆ No user-serviceable parts inside of the mobile phone, battery and charger. Recommend to send your phone to designated repair facility for service.

#### ◆ Non-ionic Radiation

- ◆ Radio equipment should be connected to the antenna by non-radiating cables, such as coaxial cable. Antenna should not be installed close to human body, unless both have metal shield, such as metal roof. You can only use the antenna which is specifically designed for the mobile phone. Use of unauthorized antennas, unauthorized alterations or additions may damage the phone or in violation of the relevant provisions, resulting in reduced performance or cause the radiation level does not meet the standard.

#### ◆ Effective Use

- ◆ Please note that the following provisions in order to get the best performance with the minimum power consumption : In communication, do not hand cover the built-in antenna place, otherwise it may affect the calls quality, and make the phone beyond normal level of output, shorten the battery time and standby time.

## ◆ Radio Frequency Energy

Your mobile phone is a low power radio transmitter and receiver. Once it is powered on, it will periodically receive and send radio signal. Network system will control the transmitted power of the mobile phone.

## ◆ FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy. If it is not installed and used in accordance with the instructions, it may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.



—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. In general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 1.0 cm from the body.

Non-compliance with the above restrictions may result in violation of RF exposure guidelines.



## 2. Your E300

### E300 Phone Layout



#### Keys Descriptions :

| No. | Keys                           | Function Descriptions                                                                                                                              |
|-----|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | Menu / Options / Edit / OK Key | Press to enter to main menu in standby mode to select / edit / confirm the operating functions.                                                    |
| 2   | Phonebook / Back Key           | Press to enter to phonebook in standby mode. Or, press to return to the previous page in the main menu.                                            |
| 3   | Dial Key                       | Press to enter the call records. Input the number in standby mode, and press this key to dial.                                                     |
| 4   | End, Power On/Off Key          | Press to end the phone call. Long press to turn off the phone.                                                                                     |
| 5   | Number Keys                    | Input numbers or characters.                                                                                                                       |
| 6   | Navigation Keys                | a) Press Up key to select shortcuts of Write Message, Messaging, Add New Contact to Phonebook, and, Alarm.<br>b) Press Down key to Alarm settings. |

|       |                      |                                                                                                                                                                                                                                                   |
|-------|----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       |                      | c) Press Left key to Profiles to select ringing mode.<br>d) Press Right key to Messaging functions.<br>e) Press the up, down, left or right keys to select the functions you need in the main menu.<br>f) Press the key in the middle to confirm. |
| 7     | LED Flashlight       | LED Flashlight                                                                                                                                                                                                                                    |
| 8 / 9 | Volume key           | To adjust the volume of your phone.                                                                                                                                                                                                               |
| 10    | Camera Key           | Press to camera function                                                                                                                                                                                                                          |
| 11    | USB/Charger Pal port | USB/Charger Pal port                                                                                                                                                                                                                              |
| 12    | LED Flashlight key   | Press for LED Flashlight                                                                                                                                                                                                                          |
| 13    | Loudspeaker          | Loudspeaker                                                                                                                                                                                                                                       |
| 14    | Viewfinder           | Viewfinder                                                                                                                                                                                                                                        |

**Icons :**

|                                                                                    |                                                                       |
|------------------------------------------------------------------------------------|-----------------------------------------------------------------------|
|   | Vertical bars indicate the signal strength of the GSM network signal. |
|   | Indicates your phone is locked.                                       |
|   | Indicates music playing                                               |
|   | Indicates the alarm clock is set                                      |
|   | Headset mode                                                          |
|   | Connected network service                                             |
|   | New missed call                                                       |
|   | New SMS                                                               |
|   | Ring (General) Mode                                                   |
|   | Silent Mode                                                           |
|   | New Multi Message                                                     |
|   | Call Transfer                                                         |
|   | BT                                                                    |
|   | Battery Icon                                                          |
|  | Charger Pal Mode                                                      |

### 3. Preparing for use

#### 3.1 Install SIM Card

The SIM card contains your private information such as your phone number and Phonebook.

·The SIM card slot is located inside the phone, for the installation, open the back cover, take out the battery and find the SIM card slot.

Put the SIM card metal face down, gently insert to the card slot, and fix it. You must turn the phone off before you replace the SIM card.

·Please operate SIM card carefully, friction or bending may damage the SIM card.

·Pay attention to save the mobile phone and its accessories such as the SIM card small parts, and place out of the reach of children.

#### 3.2 Install Memory Card (T-FLASH Card)

It is located inside the phone and it is a pluggable mobile memory card. When the phone is enable USB memory function and computer connected, transmission of the data files from the computer to mobile phone can be stored in this memory card.

Install Method:

Turn off the phone, open the back cover and take the battery out, then find the memory card slot. Put the memory card metal face down, gently insert to the card slot, and fix it. You must turn the phone off before you take the battery out.

Note: Since the phone memory is less, in the need to use the storage function, please try to store files in the memory card so as not to affect the use of your phone.

#### 3.3 Charge the battery

- The battery charge indicator: your phone can monitor and display information about the battery.
- Normally you can see the rest of the battery power from the battery power icon on the top right corner of the screen.
- When the battery power is low, the screen will show "low power".
- When the battery is being charged, it displays charging animation. When charging animation stops, it

means charging is finished.

Note: The actual standby time and call time are affected by the mobile phone usage, local network environment, SIM card and the actual settings.

- The charger can charge the battery through the phone. You must insert the battery before you start to charge.

1. Connect the charger and the micro-USB port at the bottom of the phone by the USB cable as provided.

2. Plug the charger into the main power supply socket.

Warning: You must ensure that the local standard voltage and frequency of the main power supply socket match with the voltage and power ratings of the charger.

## **4. Basic Functions**

### **4.1 Dial Call**

In the standby screen, you can press the phone number directly, then press the Dial key to make call.

Press the End key to end the call.

- International call: Press the \* key twice to enter "+" sign. Key in the country code, area code and phone number, then press the call button.

- To correct typing errors: Press the Back key to delete the last character in the screen. To clear all the input, long press the Back key or directly press the End key.

- Make phonebook call: Press the Phonebook / Back key to access the phonebook in standby screen, search & select the contact person then press the Dial key to call.

- Redial the last number: In the standby screen, press the Dial key to display the dialed calls list. Then, press the Up or Down key to select the number and press the Dial key to call.

### **4.2 Adjust Volume**

During a call, press the Volume key to adjust the call volume.

### **4.3 Answer the incoming call**

- Press the Dial key to answer. When the call vibrate, it says your phone is on call.

■ Press the End key to end the call.

■ Directly press the End key or the Back key to refuse an incoming call.

Note: If the caller identification is available, it displays caller number. (If the caller phone record is saved in the mobile phone, it displays the caller name).

#### 4.4 Call Process

During a call, you can press the Menu (Options) key to select hold, end single call, phonebook, call records, message, sound recording, mute, and other functions. Please see the next chapter "menu function".

● Call hold: Hold the current call and both parties cannot hear each other's voice at the same time.

**A:**

1. Press the phone number and Dial key to make the second call.
2. The first call will be automatically held.

**B:**

1. Press Menu (Options) key to open the mute to hold the current call.
2. Press the phone number and Dial key to make the second call.

After it is put through, one is in call state, another is in hold state; you can swap the two calls.

● End single call: end the current call.

● Phonebook: view the phonebook while calling.

● Call records: view the call records while calling.

● Message: view or send message while calling.

● Sound recording: recording while calling.

● Mute: This function can turn on or off the microphone of the mobile phone and connect the other microphone. The other side cannot hear you when the Mute function is on.

### 5. Main Menu

Please read the following guidelines to better understand the functions.

#### 5.1 Call Center

##### 5.1.1 Call history

###### ■ Missed Calls

■ You can view the last 20 missed calls. Press the Menu (Options / OK) key to proceed as follows:

- View: view the details of the phone number.
- Call: call the phone number.
- Send SMS: send SMS to the phone number.
- Send MMS: send MMS to the phone number.
- Save to phonebook: save the phone number to phonebook.
- Edit before calling: edit the phone number before calling it.
- Delete: delete the phone number.

#### ■Dialed Calls

- You can view the last 20 dialed calls. You can view, call, send SMS, save to phonebook, edit before calling and delete. Same as “Missed Call”.

#### ■Received Calls

- You can view the last 20 received calls. You can view, call, send SMS, save to phonebook, edit before calling and delete. Same as “Missed Calls”.

#### ■All Calls

You can view all the records of Missed Calls, Dialed Calls and Received Calls.

#### ■Delete Call Logs

Delete all the records of Missed Calls, Dialed Calls, Received Calls or All Calls.

### 5.1.2 Call Settings

#### 5.1.2.1 SIM1 Card Call Settings

##### ■Call Waiting

- Start : Start the “call waiting” function, the third party can call in when you are on a call. The network will give you signal sound and display another call on the screen.
- Close : If you cancel the call waiting function, the third party cannot call in when you are on a call.
- Inquiry : It is used to query the current state of the network.

##### ■Call Divert :

This function transfers the incoming call to another phone number that you specify. In the call settings



menu, select "Call divert", press the "OK" key to enter this function.

■ Call Barring: This function allows you to restrict your calls. To set this function, you need the network operator to provide network banning password first.

#### **5.1.2.2 Advanced Settings**

- Blacklist: You can open or close and set the numbers of the blacklist.
- Auto Redial: If this function is on, when the other party does not pick up your call, the phone will automatically redial over a period of time. Automatic redial is 10 times maximum.
- Call Time Reminder : This function gives prompts to you for the call time. You can set reminder time in the reminder type options of "Single" and "Periodic".
- Answer mode: You can set any key to answer calls or automatic answer via headset mode.

## 5.2 Phonebook

### 5.2.1 Searching

Quick Search: You can enter the name or telephone number, and other related information to quickly find the contacts in the phonebook. Press the # key to switch "abc" or "123" in the phonebook interface to switch the input method.

### 5.2.2 Add New Contact

In the phonebook menu, select "Add New Contact", then select "to SIM 1", "to SIM 2" or "to Phone" to add new contacts.

### 5.2.3 Options of the Contacts

Press the Options key in the Phonebook menu, you can view, send SMS, call, edit, delete, copy, send name card and phonebook settings.

#### ■Phonebook Settings

- Storage Position : You can select to save the contacts in SIM 1, SIM 2, mobile phone or all the above. If the phone only has SIM 1, this option will only display SIM 1.
- Speed Dial : When this function is on, a total of eight speed dial numbers can be set to the keys 2 ~ 9. In the standby state, long press the number key, the corresponding phone number will be dialed at once.
- Extra numbers : When the Fixed Dial Function is on, you can only dial the numbers in your Fixed Dialing Numbers (FDN) List. To open fixed dial, PIN2 code password is needed. Please check with your local operator if they support the fixed dial operation.
- Memory Status : It displays the numbers of contacts are saved out of the total allowable storage of the phonebooks of the SIM 1 / SIM 2, the phone and the Group.
- Copy Contacts : You can copy the phonebook from SIM 1 / SIM 2 to the phone or from the phone to SIM1/SIM2.
- Move Contacts : you can move the phonebook from SIM 1 / SIM 2 to the phone or from the phone to SIM 1 / SIM 2.

- Delete All Contacts : You can delete all the contacts in the phonebooks of SIM 1 / SIM 2 and the phone.

### **5.3 File Manager**

- You can use this function to manage the directories and files which are stored in the phone or in the T-Flash card.

Note: You can move the specified file or all the files and images of the T-Flash card.

### **5.4 Organizer**

#### **5.4.1 Charge Pal**

- The phone can charge another mobile phone via the USB port on the right side of the phone.
- After selecting “On” on the Charge Pal interface, connect another mobile phone or device with the USB port by a correct USB cable for charging.

Note: Charging another mobile phone or device will be ceased when the phone is in low battery.

#### **5.4.2 Calendar**

- On the Calendar interface, press the left or right key to switch the date. After selecting the date, press the Options key to select functions such as View / Add events, Jump to (specific) Date or Go to Weekly View.

#### **5.4.3 Alarm Clock**

- This phone offers five alarm clocks settings.
- Press the Edit key then set the Alarm On/Off, the Alarm Time, the Alarm Frequency (once, everyday or custom) and the Alarm Ring Tone.
- Press the Confirm key to save the complete alarm settings.

### **5.5 Message**

#### **5.5.1 Message creation**

- Edit new SMS to send.
- Edit the SMS in the SMS interface, press # key to switch the input method. After editing, you can click “options” to operate the following functions:

- Send to: send the SMS.
  - Input method: select which input method you want to edit.
  - Advanced option: number insertion is available.
  - Save: save the SMS to the draft box.
- MMS: Edit the MMS in MMS interface. You can also add image, sound and video file in MMS to send. The contents of MMS file cannot be exceeded 100k.
- You can click "options" to operate the functions:

#### 5.5.2 Inbox

This message dialogue will save SMS, MMS in the dialogue groups. SMS icon is different from multimedia message. Unread message will show as unread message icon. Read message will show as read icon.

**Note: The screen will show icon when you receive new message. If the message is full, you will not be able to receive new message. Please delete unnecessary message.**

#### 5.5.3 Draft box

■Draft box storage the not yet ready to send message to prepare for modify again and send. Specific operation please refer to the inbox.

#### 5.5.4 Outbox

■Outbox storage manage the sending message and failed message. Specific operation please refer to the inbox.

#### 5.5.5 Sent Message

■Sent message is stored messages sent successfully. Specific operation please refer to the inbox.

#### 5.5.6 Delete Message

■Delete the inbox, draft box, outbox, sent message and all messages.

### 5.5.7 Message Settings

#### ■SMS

- SIM1/SIM2 Card: enter this menu, you can set Message Center number, SMS validity, sent format, send report, reply path, preferred connection, voice mail, etc.
- Save the sent SMS: open this function, the sent message will automatically save in Sent Message.

#### ■MMS

- Data account: Choose the service provider that you need to connect.
- General Settings:
- Receive settings: you can select promptly or delay settings.
- Send and save: open this function, the MMS will be saved in sent message automatically every time.
- Storage State: check the MMS usage rate in memory card.
- Service Message:
- Service Message Settings: you can select receive all and close all.
- Information loading: can choose to ask, automatic implementation and close.

## 5.6 Multimedia

### 5.6.1 Camera

Use the camera application, you can take picture for around people or events any time. Photo will be stored in the JPG format in the "Image Viewer".

Note: please comply with all local laws and regulations on taking photographs. Please don't illegal use this function.

When the camera application open, you can see the scene that you want to shoot on the screen.

- Photo: browse the images (for details, please refer to the Image Viewer).
- Camera Settings: You can set the avoid flicking, scene mode, white balance and delayed firing settings.
- Image Settings: you can set the image size and quality.
- Restore Default: Allows you to restore to the camera's default settings.

### 5.6.2 Image Viewer

- Press left soft key to enter the menu:
- View: view the images.
- Send: to send the images via MMS or BT.
- Use as: Images can be selected for wallpaper.
- Rename: modify the image's name.
- Delete: delete the image.
- Image information: view the details of image.

### 5.6.3 Video Recorder

■ Enter to Video Recorder, in the camera preview state, press the OK key to start camera then press the right soft key to stop. Press left soft key after enter to the video recorder function, the operations as below:

- Camcorder settings: set to avoid flicking value.
- Video Settings: set video quality, you can set the video in different quality.
- In addition to set the video parameters in options, you can also use: Up and Down Key to adjust video focus.

### 5.6.4 Video Player

■ The phone supports 3GP, MP4 and AVI format video files. Press OK Key to enter to Video Player list, in this mode, you can also:

Note: Videos can only be on the "videos" directory, in order to generate a file in the video player.

- Play: play the specified video file.
- Send: send the video via BT.
- Rename: modify the video name.
- Delete: delete the video.

■Video Play:

●Press the \* and # key to adjust the volume. Press the left or right key to support fast forward and rewind. Press the up key to switch between full-screen and half-screen. Press OK key to pause and continue to play.

### 5.6.5 Audio Player

■Press left key to enter to Music Player list, press right key to return. Press side key to control volume, press left or right key to switch last one or next one. Press OK Key to pause or continue. Press left soft key to enter the playlist, click “options” to complete the following operations:

■Play: play the specified music.

■Detail information: to view the size, time, music name and player of this file.

■Update playlist: update playlist of memory card or phone. When the automatic generation of list is set to open, provide the function.

■Settings:

●List Auto: open or close automatic generation list.

●Repeat: you can specify shut, single music, all the way to a play.

●Shuffle: you can select random play on and off states.

●Background play: If you choose the open state, exit the music player interface, music can still play. Otherwise, music will automatic stop to play.

### 5.6.6 Sound Recorder

■Sound Recorder record the audio and save it in your device. You can enter the Setting interface to choose the audio quality and the storage location.

### 5.6.7 FM Radio

■You need to insert the earphone otherwise the FM Radio cannot be functioned. Once you enter radio interface, you can operate the following functions: turn on/off radio, forward search, backward search, increase volume and decrease volume.

## 5.7 Network Service

### 5.7.1 Internet Service

■ You can surf the internet, browse the relevant Web by WAP browser. For more information, please contact your network service provider. Open this menu to enter the following operations:

- Homepage: Internet's default website.
  - Bookmark: store the commonly used website.
  - Search or input the website: input the website which you want to visit, click OK to enter the website.
  - Recent Pages: the preservation record after browsed the web.
- Settings
- Data account: Select the network connection data account. If you select automatic, the phone will automatically according to the SIM card operators to select the data account.
  - Browse options: you can clear your online web cache, cookies and authentication information in this menu.

### 5.7.2 SIM toolkit

■ This function is provided by network operator, there will be new menu if your SIM card support this function. Please contact your network operator for further information of SIM toolkit (if support).

## 5.8 Profiles

■ The available profiles are General, Silent, Meeting, Outdoor. You can also set the tone, volume, alert, ring, and so forth with **Options, Customize** option, so that whenever you receive an incoming call or a new message, you can customize the use of your phone to different types of call environments.

## 5.9 Settings

### 5.9.1 Phone Settings



#### **5.9.1.1 Time and Date**

■ In this interface, you can change the following setting:

1. Set Time Zone: Set the device Time Zone.
2. Set Time/ Date: Change the Time and date manually.
3. Set format: To change the display method of the Time and date.
4. Auto Update Time: To calibrate the time and date by network.

#### **5.9.1.2 Language**

■ You can choose different language as your requirement in this interface.

#### **5.9.1.3 Preferred Input Method**

■ To choose your commonly used input method as the default input method.

#### **5.9.1.4 Display**

- Wallpaper: system provides 7 default images for wallpaper. You can also use your own image as the wallpaper by choosing the “User Defined”.
- Screen auto lock: you can set the keyboard lock time according to your own needs.
- Show date and time: click open or close to said whether display date and time in standby.

#### **5.9.1.5 Dedicated Key**

■ Dedicated key: used to set the shortcuts for specific keys.

#### **5.9.1.6 Flight Mode**

- In this interface, you could choose the flight mode and normal mode,
- If you choose Flight mode, all the network function will disable.
- The network function will restore after you choose the normal mode.

#### **5.9.1.7 Misc. Settings**

- LCD Backlight: set LCD backlight brightness and backlight time.
- Image Quality: set to open or close.

### 5.9.2 Security Settings

This interface contain some setting for improve the safety of your device.

■SIM1/SIM2 Security: you can setup or change the PIN code in this interface. Once you enable the PIN lock, it will restrict some phone function unless you input the correct PIN code to unlock it.

■Phone Security: Using this function will lock your phone. A password is required to turn this function on or off. You will be asked to enter the password when you power on the device with SIM card.

■Privacy Project: Once you enable this function, you can choose to lock the Phone book, message, call log and file manager. You may not access those function unless you input the correct password.

### 5.9.3 Network Settings

You can change the network selection for each SIM card in this interface.

To obtain the above network services, please contact your network operator.

### 5.9.4 Dual SIM Setting

■The user can refer to the SIM card usage to set the corresponding operation, this function in the double card insertion condition can choose:

- Dual SIM open: open two SIM cards at the same time.
- Only SIM1 card: open SIM1 card only.
- Only SIM2 card: open SIM2 card only.

Note: if the user only insert SIM1 card, the bar just show only SIM1 card open.

### 5.9.5 Connectivity

#### **5.9.5.1 BT**

■ You can activate BT function in this menu, including start BT, search hands free device, my device, connectivity device, settings, my BT. Start BT, you can transfer the files to the matched BT and it can be paired with a BT headset to make a call.

- Power: You can choose “activate” or “close” BT as your demand.
- Visibility: Other BT devices cannot search your BT unless you enable this function.
- My device: Used to search for new device or display already pairing successful device list record.
- Search audio device: search audio device with BT function.
- My name: display this phone’s BT name, and you can also modify it.
- Advanced:
  - Audio path: set audio path to save as your phone or BT hands free device.
  - My Address: Display this phone’s BT address.

#### **5.9.5.2 Data Account**

■ Select the corresponding data account according to your needed connection network services. You can edit, add, delete and change default account.

#### **5.9.6 Restore factory settings**

■ This feature would reset parts of functions as those configured at the factory. The factory default password is 1122.

## **6. Appendix**

Appendix1: Carry on the following simple examination before you contact with after-sales service, perhaps can help you avoid the redundant maintenance time and expense to waste.

**Common problems and solutions**

| Common problems                 | The causes and solutions                                                                                                                                                                                                                                                                                                                                                     |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Unable to boot                  | <ol style="list-style-type: none"><li>1. Check whether the battery power is exhausted, please charge the battery.</li><li>2. Check whether the battery is bad contact. Please remove it first and reinstall, then retry boot.</li></ol>                                                                                                                                      |
| SIM card error                  | <ol style="list-style-type: none"><li>1. SIM card metal surface have dirt, use clean cloth to brush the SIM card metal contact point</li><li>2. Reinstall the SIM card.</li><li>3. SIM card is damaged, please replace SIM card.</li></ol>                                                                                                                                   |
| Poor signal                     | Check on the signal strength indicator of the screen, 5 bars indicate a strong signal, less than 2 bars indicate a weak signal.                                                                                                                                                                                                                                              |
| Unable to dial out              | <ol style="list-style-type: none"><li>1. You may set to hide your phone number, but your network operator does not provide the service.</li><li>2. Surrounding environment may have a strong interference signal</li><li>3. You may activate call barring function.</li><li>4. You may activate the line2, but your network operator does not provide the service.</li></ol> |
| Unable to charge                | <ol style="list-style-type: none"><li>1. Battery may have over-discharge, it need to connect the charger after a period of time to charge</li><li>2. Battery performance have been worse</li></ol>                                                                                                                                                                           |
| Unable to connect the network   | <ol style="list-style-type: none"><li>1. The signal is weak, or around the radio interference.</li><li>2. SIM card is invalid, please contact with your network operator.</li></ol>                                                                                                                                                                                          |
| Unable to enter to service menu | <ol style="list-style-type: none"><li>1. Your SIM card may not support the service function</li><li>2. Parameters of GPRS were changed.</li></ol>                                                                                                                                                                                                                            |